

## ROS: Tracking AR tags with USB camera

*The objective of this lab is to learn how to use camera in ROS for tracking AR tags.*

### SETTING UP YOUR COMPUTER

Open terminal window.

Clone your git repository to your home folder:

```
$ git clone URL_for_<yourname>-rtech_repository
```

Use `ls` to confirm that `<yourname>-rtech` has been downloaded to your home folder.

### MOUNTING A CAMERA ON THE ROBOT

In this lab you are going to:

- (1) Install ROS package for USB cameras
- (2) Calibrate the camera for distance sensing
- (3) Install ROS package for tracking AR tags
- (4) Setup launch-files for launching USB camera and AR tracking
- (5) Use RViz for displaying camera images
- (6) Update R2D2's description so that its `lense` link acts as the base for the camera

(1) Connect the web camera to your computer and if your computer does not have `usb_cam` ROS package installed, install it by using `apt-get` as follows:

```
$ sudo apt-get install ros-kinetic-usb-cam
```

In order to confirm that `usb_cam` has been properly installed, run:

```
$ roslaunch usb_cam usb_cam-test.launch
```

What do you see? Do you see the image from the recently connected Logitech USB camera? If you would like to change anything in `usb_cam-test.launch`, first copy the file to an *appropriate* place in your catkin workspace.

(2) Next, you need to calibrate your USB camera. We will use the steps given here:

[http://wiki.ros.org/camera\\_calibration/Tutorials/MonocularCalibration](http://wiki.ros.org/camera_calibration/Tutorials/MonocularCalibration)

In short:

- 1) Use `rostopic list` to see what is the namespace for your camera.
- 2) Then run the camera calibration node. Make sure to use the correct topic name and namespace.

```
$ rosruncamera_calibration cameracalibrator.py --size 8x6 --square 0.036 image:=/usb_cam/image_raw camera:=/usb_cam
```
- 3) Move the 8-by-6 grid in front of the camera until you can press buttons for *calibrate*, *save*, and *commit*.

(3) Now, if your computer does not have `ar_track_alvar` ROS package installed, install it by using `apt-get` as follows:

```
$ sudo apt-get install ros-kinetic-ar-track-alvar
```

**(4)** Create a new launch-file for my\_r2d2 ROS package and name it `ar_tracker.launch`.

Copy the contents of `usb_cam-test.launch` (from `usb_cam`) and `pr2_indiv_no_kinect.launch` (from `ar_track_alvar`) into your `ar_tracker.launch`.

In `ar_tracker.launch` change the default values for `cam_image_topic` and `cam_info_topic`. Let's also set `camera_frame_id` and `output_frame` to "lense".

Now you should be all set for launching the camera with AR tag tracking.

First roslaunch the R2D2 launch-file from the last lab, then, in a separate terminal window, launch the newly created `ar_tracker.launch`.

**(5)** To visualize images from the camera, use `ADD`-button to add Image to your RViz configuration. Make sure to set correct image topic name.

Next, use the `ADD`-button to add a Marker.

If everything is working, you should see images from the camera in a sub-window in RViz and when you place an AR tag in the camera's field of view, you should see marker(s) relative to camera frame, i.e. relative to `lense`.

**(6)** Next, set up the R2D2 description so that the `lense` link is the camera and in its default state the camera is looking straight ahead. For that, create a new empty link called `eye` that is jointed with the `lense`. Set the orientation between `lense` and `eye` so that when you move AR tag away from the camera, you would see the same behavior in RViz with the AR tag markers. Make sure that movement in up-down and left-right are also working properly.

**>>> Show the result to your lab instructor! <<<**

## CLEAN UP YOUR WORKSPACE

**NB! Before you leave the lab, make sure you have pushed all the files in your catkin workspace to your git cloud service.**

In terminal, **cd** to **<yourname>-rtech**

Type

```
git config user.email "youremail@example.com"
```

Type

```
git status
```

You should now see all the new and modified files in red.

Prepare the relevant files for the commit.

```
git add file_name_in_red1 file_name_in_red2
```

When you now type

```
git status
```

you should see all the added files in green. You are now ready to commit changes. Type

```
git commit -m "Insert a brief explanation"
```

Your changes have now been committed but not yet uploaded to the cloud. To upload your files, type

```
git push
```

In your web browser, **verify that all the files** have been uploaded to the **<yourname>-rtech** repository.

Delete the **<yourname>-rtech** folder and any other files you created from the lab's computer.